




STRIKEFORCE
BY PALADIN™

PARTS MANUAL



HYDRAULIC BREAKER


DX Series

D&A 17V

SERIAL NUMBER: _____

MODEL NUMBER: _____220128_____

Manual Number:
Date: Februray 2025
Rev.




2003-17

PART LIST - D&A 17V MAIN BODY (POWER CELL) ASS'Y

NO	PART NO	PART DESCRIPTION	Q'TY	REMARK
2-0	DB017V0002	MAIN BODY (POWER CELL) ASS'Y	1set(s)	
1-1	B017V-11100	CYLINDER	1	
1-2	007002-05300	DUST SEAL	1	
1-3	007004-05300	U-PACKING	1	
1-4	B008V-118E0	HOSE ADAPTER	2	
1-5	B008-11900	UNION CAP	2	
1-6	007001-0180P	O-RING	3	
1-7	004012-10400	RO PLUG	5	
1-8	007001-0110P	O-RING	5	
1-9	B017V-11201	PISTON	1	
1-10	B017V-11300	CYLINDER BUSH	1	
1-11	007005-05000	GAS SEAL	1	
1-12	007004-05000	U-PACKING	2	
1-13	007001-0700G	O-RING	3	
—	B017V-11456	VALVE SET	1set(s)	14,15,16,17,18
1-14	B017V-11400	VALVE	1	
1-15	B017V-11500	VALVE BUSH	1	
1-16	B017V-11600	VALVE CAP	1	
1-17	007001-0320P	O-RING	1	
1-18	007001-0200P	O-RING	1	
1-19	B017V-12100	FRONT HEAD	1	
1-20	B015V-12301	LOWER BUSH	1	
1-21	B008-12650	SPRING PIN	1	
1-22	004013-10800	GREASE NIPPLE	1	
1-23	B015-12600	CHISEL PIN (TOOL PIN)	1	
1-24	B008-12610	CHISEL STOPPER PIN (TOOL STOPPER PIN)	1	
1-25	B008-12630	SPRING	1	
1-26	004045-05035	SPRING PIN	1	
1-27	004014-10400	HOLLOW PLUG	1	
—	B017V-12200	THROUGH BOLT SET	4set(s)	28,29,30
1-28	B017V-12210	THROUGH BOLT	4	
1-29	B017V-12220	THROUGH BOLT WASHER	4	
1-30	B017V-12230	THROUGH BOLT TOP NUT	4	
1-32	B017V-13100	BACK HEAD	1	
—	B008-13200	GAS VALVE SET	1set(s)	6,33,34,35
1-33	B008-13210	GAS VALVE	1	
1-34	B008-13220	GAS VALVE CAP	1	
1-35	007001-0080P	O-RING	1	
—	B017V-SK000	SEAL KIT	1set(s)	

PART LIST - D&A 17V BOX HOUSING ASS'Y


NO	PART NO	PART DESCRIPTION	Q'TY	REMARK
2	B017F-55000	BOX HOUSING ASS'Y	1set(s)	
2-1	B017F-55010	BOX HOUSING	1	
2-2	B017V-35100	BOTTOM DAMPER	1	
2-3	B008V-35200	UPPER DAMPER	1	
2-4	B015V-35502	MC PAD (SHELL PAD)	1	
2-5	B015V-35602	MC PAD (SHELL PAD)	1	
2-6	B008V-27419	MC PAD (SHELL PAD)	4	
2-7	B008V-2731A	MC PAD (SHELL PAD)	3	
2-8	007001-0340P	O-RING	11	
2-9	B015V-12800	RUBBER COVER	1	
2-10	B008V-12700	GREASE COVER	1	
2-11	B008V-27012	HOSE COVER	1	
2-12	B008V-27129	GAS COVER	1	
2-13	002A01-10020	HEX BOLT	4	
2-14	002AH8-10000	SPRING WASHER	4	



2003-17


PART LIST - D&A 17V STICKER/NAME PLATE

NO	PART NO	PART DESCRIPTION	Q'TY	REMARK
3	DandA-NAME-10	NAME PLATE	1	
4	004054-03060	RIVET	4	
5	B008V-DS1250	NAME DECAL (L)	1	
6	B008V-DS2250	NAME DECAL (R)	1	
7	B017V-DS0260	MODEL DECAL	2	
8	B008V-DSS00-03	STICKER - DANGER	1	
9	B008V-DS071	STICKER - GREASE	1	
11	B008V-DS0310	STICKER - OUT PORT	1	
12	B008V-DS0320	STICKER - IN PORT	1	
13	B063V-DS000-10	STICKER - WARNING (GAS16)	1	
	B063V-DS000-12	STICKER - WARNING (GAS10)	1	for SKID
14	B63V-DSS00-06	STICKER - HOT CAUTION	1	
16	B132V-DS000-15	STICKER-LOOSE BOLT CAUTION	1	
17	B140F-DS0010	STICKER - WARNING DISCHARGE	1	
18	NOISE-11000	STICKER - NOISE	1	




PART LIST - D&A 17V MOUNT CAP

NO	PART NO	PART DESCRIPTION	Q'TY	REMARK
A1	B008V-354A0	ADAPTER PLATE SET (W/O MOUNT CAP)	1set(s)	
A1-1	B008V-35400	ADAPTER PLATE	1	
A1-2	002001-18060	HEX BOLT	2	
A1-3	002003-1800N	HEX NUT	2	
A2		MOUNT CAP ASS'Y	1set(s)	TAILOR MADE AS PER ORDER
A2-1		MOUNT CAP	1	TAILOR MADE AS PER ORDER
A2-2		BRACKET PIN	2	TAILOR MADE AS PER ORDER
A2-3		BRACKET PIN BUSH	4	TAILOR MADE AS PER ORDER
A2-4		STOP RING	2	TAILOR MADE AS PER ORDER
A2-5		HEX BOLT	2	TAILOR MADE AS PER ORDER
A2-6		HEX NUT	4	TAILOR MADE AS PER ORDER
A2-7	002A01-18060	HEX BOLT	12	
A2-8	002AH8-18000	SPRING WASHER	12	
A2-9	002A11-1800N	NYLON NUT	12	
A8	B008V-354B0	ADAPTER BASE PLATE SET (W/O MOUNT CAP)	1set(s)	
A8-1	B008V-35410	ADAPTER BASE PLATE	1	
A8-2	002A01-18060	HEX BOLT	12	
A8-3	002AH8-18000	SPRING WASHER	12	
A8-4	002A11-1800N	NYLON NUT	12	
A9	B017V-65A00	MOUNT CAP ASS'Y (SKID)	1set(s)	
A9-1	B008V-65000	MOUNT CAP WA	1	
A9-2	002A01-18060	HEX BOLT	12	
A9-3	002AH8-18000	SPRING WASHER	12	
A9-4	002A11-1800N	NYLON NUT	12	



PART LIST - D&A 17V CHISEL (TOOL)


NO	PART NO	PART DESCRIPTION	Q'TY	REMARK
B1	B015-12500	CONICAL POINT (CONICAL MOIL POINT)		
B2	B015-12510	MOIL POINT (PYRAMID MOIL POINT)		
B3	B015-12520	CROSS CUT (CHISEL POINT H)		
B4	B015-12530	IN-LINE (CHISEL POINT V)		
B5	B015-12540	FLAT END (BLUNT)		
B6	B015-12550	TAMPING PAD (TAMPING TOOL)		
B7	B015-12560	ASPHALT CUTTER		
B8		CORE CONICAL POINT (CORE MOIL POINT)		TAILOR MADE AS PER ORDER
B9		ELEPHANT FOOT TOOL (POST DRIVER)		TAILOR MADE AS PER ORDER



2004-17


PART LIST - D&A 17V GAS CHARGING

NO	PART NO	PART DESCRIPTION	Q'TY	REMARK
D1	BGK01-N2DS1	GAS CHARGING KIT - STANDARD	#####	
D1-1	BGK01-N2410	3 WAY VALVE SET	1set(s)	
D1-2	BGK00-N22D0	GAS HOSE	1	
D1-3	BGK00-G220A	GAS ADAPTER	1	
D1-4	BGK00-N2430	COUPLING	1	
D1-5	BGK00-N2420	CAP NUT	1	
D1-9	DBGM010	GAS CHARGING MANUAL	1	
D2	BGK01-N2V11	GAS CHARGING KIT - INDIA	#####	
D1-1	BGK01-N2410	3 WAY VALVE SET	1set(s)	
D1-2	BGK00-N22D0	GAS HOSE	1	
D1-3	BGK00-G220A	GAS ADAPTER	1	
D2-4	BGK00-N34F0	COUPLING	1	
D2-5	BGK00-N3420	CAP NUT	1	
D2-6	BGK00-N3490	GAS CYLINDER ADAPTER	1	
D2-7	BGK00-N3480	RING	1	
D1-9	DBGM010	GAS CHARGING MANUAL	1	
D3	BGK01-N2VC1	GAS CHARGING KIT - CHINA	#####	
D1-1	BGK01-N2410	3 WAY VALVE SET	1set(s)	
D1-2	BGK00-N22D0	GAS HOSE	1	
D1-3	BGK00-G220A	GAS ADAPTER	1	
D3-4	BGK00-N34F0	COUPLING	1	
D3-5	BGK00-N3420	CAP NUT	1	
D3-6	BGK00-N34C0	GAS CYLINDER ADAPTER	1	
D3-7	BGK00-N3480	RING	1	
D1-9	DBGM010	GAS CHARGING MANUAL	1	
D4	BGK01-N2BM1	GAS CHARGING KIT - BRAZIL	#####	
D1-1	BGK01-N2410	3 WAY VALVE SET	1set(s)	
D1-2	BGK00-N22D0	GAS HOSE	1	
D1-3	BGK00-G220A	GAS ADAPTER	1	
D4-4	BGK00-N34F0	COUPLING	1	
D4-5	BGK00-N3420	CAP NUT	1	
D4-6	BGK00-N34B0	GAS CYLINDER ADAPTER	1	
D4-7	BGK00-N3480	RING	1	
D1-9	DBGM010	GAS CHARGING MANUAL	1	
D5	BGK01-N2GE1	GAS CHARGING KIT - GERMANY	#####	
D1-1	BGK01-N2410	3 WAY VALVE SET	1set(s)	
D1-2	BGK00-N22D0	GAS HOSE	1	
D1-3	BGK00-G220A	GAS ADAPTER	1	
D5-4	BGK00-N34F0	COUPLING	1	
D5-5	BGK00-N3420	CAP NUT	1	
D5-6	BGK00-N3480	RING	1	
D1-9	DBGM010	GAS CHARGING MANUAL	1	
D6	BGK01-N2A01	GAS CHARGING KIT - NORTH AMERICA	#####	
D1-1	BGK01-N2410	3 WAY VALVE SET	1set(s)	
D1-2	BGK00-N22D0	GAS HOSE	1	
D1-3	BGK00-G220A	GAS ADAPTER	1	
D6-4	BGK00-NALL0	COUPLING	1	
D6-5	BGK00-NCAL1	CAP NUT	1	
D1-9	DBGM010	GAS CHARGING MANUAL	1	
D8	BGK00-B0300L	GAS CYLINDER	1	
D9	BGK01-B0300LS	GAS CYLINDER - INDIA	#####	
D9-1	BGK00-B0300L	GAS CYLINDER	1	
D9-2	BGK00-N3500	GAS CYLINDER ADAPTER	1	
D9-3	BGK00-N3510	COUPLING	1	
D9-4	BGK00-N3520	CAP NUT	1	




PART LIST - D&A 17V HYD HOSE

NO	PART NO	PART DESCRIPTION	Q'TY	REMARK
C1	100802-AA170044	HYD HOSE_1700	2	
C2	100802-AA250044	HYD HOSE_2500	2	for SKID



PART LIST - D&A 17V LITERATURE

NO	PART NO	PART DESCRIPTION	Q'TY	REMARK
E1	DBOM100	OPERATOR'S MANUAL	1	
E2	DBPM100-017V	PART LIST	1	



PART LIST - D&A 17V TOOL BOX

NO	PART NO	PART DESCRIPTION	Q'TY	REMARK
H1	B017V-TB001	TOOL BOX	1	



STRIKE*  *FORCE TM
BY PALADIN